

Update Requirements:


macOS 10.10 - 10.13

For: JAM 96k, MiC 96k, or MiC Plus

Check current firmware version

- 1) Plug JAM or MiC or MiC Plus via USB into Mac computer using USB cable that came in box with Apogee device.
- 2) Click the  icon to open the menu. Hold the <OPTION> key on Apple keyboard and item in menu will change to “System Information”. Select this.
- 3) Navigate to Hardware > USB and in the Device Tree click on the JAM or MiC.
- 4) Verify the “Version” number is 3.0.2 (MiC Plus Version number is 1.11)

*JAM 96k & MiC 96k: If version is 1.x (like 1.0.5), or 2.x (like 2.02), the device does not need an update.



Perform Update

- 1) QUIT the System Information app. Keep the JAM/MiC 96k or MiC Plus connected via USB to your Mac.
- 2) Unzip and open the fwugui.app



- 3) When app says “Ready to update...” click UPDATE
- 4) Wait until the programming block reaches 255



- 5) When the app says firmware is up to date, you can QUIT the updater app. (Note: MiC Plus firmware will go from version 1.0.11 to 1.0.12)

