


Hardware Connections



Hardware Settings



Software Settings

Open the Hammerfall 9652 Control Panel, set Clock Mode to AutoSync and set Pref Sync Ref to ADAT 1 In

In the audio software application employed, select the 9652 ASIO driver as the active interface device.

