


# ApogeeConnects : Rosetta 800 - Digidesign DIG192

## Hardware Connections



Connect Rosetta #1 WC Out to a BNC "T" connector installed on Rosetta #2 WC In. Connect the other side of the BNC "T" connector to the DIG192 Ext. Clock In; do not terminate this input. Alternatively, use an Apogee Big Ben as a Master Clock and connect each device to it's own Big Ben WC Output.

## Hardware Settings

